

V2101 Series WinCE User's Manual

First Edition, January 2010

www.moxa.com/product

MOXA®

© 2010 Moxa Inc. All rights reserved.
Reproduction without permission is prohibited.

V2101 Series WinCE User's Manual

The Moxa software described in this manual is furnished under a license agreement and may be used only in accordance with the terms of that agreement.

Copyright Notice

Copyright © 2010 Moxa Inc.
All rights reserved.
Reproduction without permission is prohibited.

Trademarks

MOXA is a registered trademark of Moxa Inc.
All other trademarks or registered marks in this manual belong to their respective manufacturers.

Disclaimer

Information in this document is subject to change without notice and does not represent a commitment on the part of Moxa.

Moxa provides this document “as is,” without warranty of any kind, either expressed or implied, including, but not limited to, its particular purpose. Moxa reserves the right to make improvements and/or changes to this manual, or to the products and/or the programs described in this manual, at any time.

Information provided in this manual is intended to be accurate and reliable. However, Moxa assumes no responsibility for its use, or for any infringements on the rights of third parties that may result from its use.

This product might include unintentional technical or typographical errors. Changes are periodically made to the information herein to correct such errors, and these changes are incorporated into new editions of the publication.

Technical Support Contact Information www.moxa.com/support

Moxa Americas:

Toll-free: 1-888-669-2872
Tel: +1-714-528-6777
Fax: +1-714-528-6778

Moxa China (Shanghai office):

Toll-free: 800-820-5036
Tel: +86-21-5258-9955
Fax: +86-10-6872-3958

Moxa Europe:

Tel: +49-89-3 70 03 99-0
Fax: +49-89-3 70 03 99-99

Moxa Asia-Pacific:

Tel: +886-2-8919-1230
Fax: +886-2-8919-1231

Table of Contents

Chapter 1	Introduction	1-1
	Overview.....	1-2
	Software Specifications	1-2
	Application Development Environment	1-2
	Networking and Communication Capabilities.....	1-3
	Supporting Services and Daemons	1-3
	Graphics Tools.....	1-3
	Supporting Drivers	1-3
	Memory and File Systems	1-4
	Hive-Based Registry.....	1-4
Chapter 2	Software Configuration	2-1
	Starting Your V2101-CE Computer	2-2
	Resetting Your V2101-CE Computer.....	2-3
	Cold-Start	2-3
	Warm-Start	2-3
	Reset to Factory Default	2-3
	Changing the Network Settings	2-3
	Operating Your V2101-CE Computer with a Telnet Client.....	2-5
	User/Group Management.....	2-6
	Adjusting the System Time	2-6
	Adjusting the Time Zone	2-6
	Starting and Stopping Services	2-7
	Troubleshooting Network Connectivity.....	2-7
	Simple Network Management Protocol (SNMP).....	2-9
	Setting Up the LVDS Panel	2-10
	Inserting a USB Storage Device into the Computer.....	2-12
	2 RS-232/422/485 Serial Ports.....	2-12
	Accessing Files through File Sharing	2-13
	BIOS Status Notification	2-14
	How to Determine the Firmware Build Version.....	2-15
Chapter 3	Management Tools.....	3-1
	System Information.....	3-2
	Serial Port Configuration	3-3
	Process (Thread) Monitoring/Control.....	3-4
	Services Monitoring/Control	3-5
	Display	3-6
	User/Group Management.....	3-7
	Auto Launch Configuration	3-9
	Web Server Configuration Page.....	3-9
Chapter 4	System Recovery	4-1
	Reset to Factory Default	4-2
	Recovery Procedure.....	4-3
	Recovery Environment	4-3
Appendix A	Firmware Upgrade Procedure.....	A-1

Thank you for purchasing the Moxa V2101 Series of x86 ready-to-run embedded computers. This manual introduces the software configuration and management of V2101 embedded computers running the Windows CE operating system. For hardware installation, connector interfaces, setup, and upgrading the BIOS, please refer to the V2101 Series Hardware User's Manual.

Microsoft Windows CE is an open, scalable, 32-bit operating system that allows you to build a wide range of innovative, small footprint devices. A typical Windows CE-based device is designed for a specific use, and often runs disconnected from other computers, or distributed as a front-end to a centralized host. Examples include enterprise tools, such as industrial controllers, communications hubs, point-of-sale terminals, and display devices, such as HMI, advertisement appliances, and interactive panels.

This chapter covers the following topics:

- ❑ **Overview**
- ❑ **Software Specifications**
 - Application Development Environment
 - Networking and Communication Capabilities
 - Supporting Services and Daemons
 - Graphics Tools
 - Supporting Drivers
- ❑ **Memory and File Systems**
- ❑ **Hive-Based Registry**

Overview

V2101 embedded computers are based on the Intel Atom Menlow XL x86 processor and feature 2 serial ports, dual Gigabit LAN ports, 4 USB 2.0 hosts, and an SD socket. The V2100 Series offers both VGA and LVDS outputs, making it particularly well suited for industrial applications, such as SCADA and factory automation.

The V2101's 2 serial ports makes it ideal for connecting a wide range of serial devices, and the dual 10/100/1000 Mbps Ethernet ports offer a reliable solution for network redundancy, promising continuous operation for data communication and management. As an added convenience, the V2101 computers have three DIs and three DOs for connecting digital input/output devices. In addition, the SD and USB ports provide the V2101 computers with the reliability needed for industrial applications that require data buffering and storage expansion.

Pre-installed with Windows CE 6.0, the V2101 Series provides programmers with a friendly environment for developing sophisticated, bug-free application software at a lower cost.

All V2101 models support a wide operating temperature range of -40 to 85°C for harsh industrial environments.

Software Specifications

The V2101-CE embedded computer provides the following common, popular application development features, networking/communications capabilities and supporting services/daemons to make the Windows CE environment into an easy and convenient programming tool. The software features of the V2101-CE embedded computer are listed below:

Application Development Environment

- **Microsoft .Net Compact Framework 2.0**—Microsoft .NET CF is a software package designed by Microsoft for connecting information, people, systems, and devices. One of the main features of .Net CF is the use of XML Web services, which allow small, discrete, building-block applications to connect to each other and to other, larger applications over the Internet. Microsoft Visual Studio .NET and the Microsoft .NET Framework allow developers to develop XML Web services quickly, and integrate them easily with other applications.
- **C/C++ Programming Languages**—You can use the eVC4++ or Visual Studio 2005 to develop C/C++ programs.
- **COM and DCOM**—The Component Object Model (COM) is a platform-independent, object-oriented system for creating binary software components that can interact with other COM-based components in the same process space, in other processes, or on remote devices.
- **Message Queuing (MSMQ)** —The Message Queuing (MSMQ) implementation makes it possible for applications to communicate with other applications across networks and systems that might be temporarily offline.
- **SOAP Toolkit**—The client-side SOAP Toolkit functionality in Microsoft Windows CE allows an application to invoke Web service operations while the server-side functionality maps invoked Web service operations to Component Object Model (COM) object method calls.
- **XML**—Extensible Markup Language (XML) is the universal format for data on the Web. XML allows developers to describe and deliver rich, structured data from any application in a standard, consistent way. XML does not replace HTML, but is a complementary format.

Networking and Communication Capabilities

- **Simple Network Management Protocol (SNMP)**—Monitors remote connections to the network.
- **Simple Network Time Protocol (SNTP) Client**—Provides support for synchronizing the device's system time with an SNTP server, and supports Daylight Saving Time.
- **Serial Communications**—Includes a special driver for Moxa serial ports.
- **Network Utilities (IpConfig, Ping, Route)**—Utilities for troubleshooting various network problems.
- **TCP/IP**—Includes IP, Address Resolution Protocol (ARP), Internet Control Message Protocol (ICMP), Internet Group Membership Protocol (IGMP), Transmission Control Protocol (TCP), User Datagram Protocol (UDP), name resolution and registration, DNS Client, and DHCP.
- **Dial-up Networking**—Consists of RAS client API and the Point to Point Protocol (PPP). RAS and PPP support Extensible Authentication Protocol (EAP) and RAS scripting
- **PPPoE**—Point-to-Point Protocol over Ethernet (PPPoE) provides the ability to connect a network of hosts, over a simple bridging access device, to a Remote Access Concentrator.

Supporting Services and Daemons

- **FTP Server**—A sample server used for transferring files to and from remote computer systems over a network using TCP/IP.
- **File Server**—The File Server functionality in Microsoft® Windows® CE enables clients to access files and other resources over the network.
- **Telnet Server**—A sample server that allows remote administration through a standard telnet client.
- **Web Server (IIS)**—Includes ASP, ISAPI, and Web Administration ISAPI Extensions.

Graphics Tools

- **Graphics Device Interface (GDI)**—Provides information about the fundamental graphics architecture for Windows CE.
- **Direct3D Mobile Display Drivers**—Provides information about creating a display driver that supports Direct3D Mobile.
- **DirectDraw Display Drivers**—Provides information about creating a display driver that supports DirectDraw.
- **Video Codecs and Renderers**—DirectShow Video Renderer, MPEG-I Video Codec, MS RLE Video Codec, Video/Image Compression Manager, WMV/MEPG-4 Video Codec.

Supporting Drivers

- **Watchdog Driver**—Provides a Watchdog API for use with applications.

Memory and File Systems

The V2101 has 1 GB of SDRAM space built-in; however, the available memory space is 512 MB due to the limitations imposed by Windows CE 6.0. The main memory has a capacity of about 480 MB in which the operating system and user applications run. The kernel image occupies the rest of the space.

The V2101-CE's internal file system controls access to the compact flash card and a RAM disk. The file system provides persistent storage for applications and related data, even when the main power supply is lost. When the system resets, all files stored in RAM disk will be lost.

The root directory is a ROM file system, which differs from the system used by Moxa's UC-7400-CE embedded computer. The V2101-CE root file system is a persistent file system. There is no any RAM file system stored in V2101-CE.

The internal file system is uses a FAT (File Allocation Table). This means that the internal file system of the computer provides the ability to mount external FAT file systems.

The additional file systems on USB and CompactFlash storage devices are placed at the root of the internal file system. If you intend to use these devices to port data between your PC and the V2101-CE computer, please format them as the FAT file system on your PC.

Hive-Based Registry

The registry for the V2101-CE is a hive-based registry, in contrast to a RAM-based registry. The hive-based registry stores registry data inside files, or hives, which can be kept in a file system, which removes the need for performing backup and restore on power off. The registry data is stored in the **\Registry** directory.

2

Software Configuration


In this chapter, we explain how to operate a V2101-CE computer either directly, or from a PC over the network. In addition, we explain how to handle system time adjustment, troubleshoot network connectivity, and other operations. Some of these operations can be handled with system commands after gaining access to the computer, and others can be done by using a “System Manager” described in a later chapter.

This chapter covers the following topics:

- Starting Your V2101-CE Computer**
- Resetting Your V2101-CE Computer**
 - Cold-Start
 - Warm-Start
 - Reset to Factory Default
- Changing the Network Settings**
- Operating Your V2101-CE Computer with a Telnet Client**
- User/Group Management**
- Adjusting the System Time**
- Adjusting the Time Zone**
- Starting and Stopping Services**
- Troubleshooting Network Connectivity**
- Simple Network Management Protocol (SNMP)**
- Setting Up the LVDS Panel**
- Inserting a USB Storage Device into the Computer**
- Accessing Files through File Sharing**
- BIOS Status Notification**
- How to Determine the Firmware Build Version**

Starting Your V2101-CE Computer

Connect the display monitor to the V2101-CE computer, and then power it up by connecting it to the power adaptor. It takes about 30 to 40 seconds for the system to boot up. During the boot-up process you should see the “Windows Embedded CE 6.0” loader image displayed on your monitor, along with a progress bar.



Once the system is ready, the desktop will appear on your monitor.



Resetting Your V2101-CE Computer

Cold-Start

Press power button and then press it again. The computer will reboot itself right away.

Warm-Start

To reboot the computer when the power is on, push the reset button on the side panel and then release it within 1 second. The computer will reboot itself.

Reset to Factory Default

If the computer is not working properly and you want to load factory default settings, press “8” when the “Windows Embedded CE 6.0” loader image is displayed during the first 4 or 5 seconds of the power on sequence. The optional prompts are described step by step as follows:

Step1: Scan Disk (Automatically).

Windows CE 6.0 supports the FAT file system. Sometimes, due to unstable power or application issues, the files, directories, or FAT table could be damaged. The “Scandisk” routine will help you scan the file system and auto-fixed file or directory corruption problems.



ATTENTION

After running Scan Disk, you might find some files named “FILE00xx.chk,” which means some files or directories were damaged and have been fixed.

Step2: Are you sure to reset system configuration to default? (y/n)

Type “Y” to load factory default settings and the configuration file.

Step3: Are you sure to clean all files? (y/n)

You can clear all garbage files and directories by selecting this option.

Step4 Proceeds? (y/n)

Type “Y” to start the Reset to Factory Defaults Procedure. After the factory default configuration has been loaded, the system will reboot automatically.

Changing the Network Settings


The V2101-CE computer comes with two network interfaces. The default IP addresses and netmasks of the network interfaces are as follows:

	Default IP Address	Netmask
LAN 1	192.168.3.127	255.255.255.0
LAN 2	192.168.4.127	255.255.255.0

There are two ways for you to change your network setting.

Use Windows CE Network Control Panel utility

Step1: Move you mouse go to the [Start] → [Settings] → [Network and Dial-Up Connections].



Step2: Right-Click the LAN icon and click the [Properties]

Step3: Click “OK” button after configuration is done.

Use telnet client to logon to V2101-CE

Normally, you are required to change them because they are located on a different local network from that of your development workstation. Without changes, you cannot connect to them directly. Use the *netconfig* utility to complete the task. Type *netconfig -h* to get help on this utility.

```
\> netconfig -h
```

```
Usage: netconfig -n <AdapterName | Alias> [-EnableDHCP]
[-i <IP address>] [-m <netmask>] [-g <gateway>] [-d <DNS server>]
[-w <WINS Server>] [-noask]
e.g.: netconfig -n LAN1 -i 192.168.10.101 -g 192.168.10.254
      : netconfig -n LAN1 -EnableDHCP
```

Alias:

```
LAN1=PCI\RTCENIC1
LAN2=PCI\RTCENIC2
```

For example, your development workstation has a LAN port at 192.168.1.5 and the Domain Name Server (DNS) is at 192.168.2.6. Execute the following command.

```
\> netconfig -n LAN1 -i 192.168.1.5 -m 255.255.255.0 -g 192.168.1.254 -d 192.168.2.6
```

Use command *netconfig* to view the new settings.

```
\> netconfig
```

```
Ethernet Adapter [PCI\RTCENIC1]
IP Address:    192.168.1.5
SubNet Mask:   255.255.255.0
Gateway:      192.168.1.254
DNS:          192.168.2.6
```

```
Ethernet Adapter [PCI\RTCENIC2]
IP Address:    192.168.4.127
SubNet Mask:   255.255.255.0
Gateway:
DNS:
```

Operating Your V2101-CE Computer with a Telnet Client

Before using the Telnet client, we suggest that you change the network settings of the computer (see the section “Changing the Network Settings”) so that at least one of the network ports is situated in the same subnet segment as your development workstation.

Use a crossover Ethernet cable to connect your development workstation directly to the target computer, or use a straight-through Ethernet cable to connect the computer to a LAN hub or switch. Next, use a Telnet client on your development workstation to connect to the Telnet console utility of the target computer. After a connection has been established, type the login name and password as requested to log on to the computer.

After logging in through the Telnet client, a list of commands will be available for operating the computer. Use *HELP* to display all of the commands, or type *HELP [command name]* to display extended help for the selected command. Some of these commands, such as *DATE* and *TIME*, are very useful for managing the computer's system time. Other commands, such as *DIR* and *MKDIR*, are good utilities for file management. For example, to inspect the file structure of the root directory, type *DIR*.

```
\> dir /b
```

```
Network
RAMDISK
BLDR
SPLASH.BMX
EBOOT.BIX
BOOT.INI
NK.BIN
Windows
Temp
Registry
Program Files
My Documents
Control Panel.lnk
Documents and Settings
```

Application Data Recycled



ATTENTION

You can only create 9 WinCE Telnet clients at the same time.

User/Group Management

List Current User:

Use the command `userlist` to display the information of existing users.

```
\> userlist
```

Admin (ftpd, telnetd, administrators)

Adjusting the System Time

Setting the System Time Manually

Use the **date** and **time** command line utilities to query the current system date/time or set a new system date/time.

```
\> date
```

The current date is: Monday, January 04, 2010

Enter the new date (mm-dd-[yy]yy): 01-04-10

```
\> date /T
```

Monday, January 04, 2010

```
\> time
```

The current time is: 4:02:00 PM

Enter the new time (hh:mm:ss): 16:02:00

```
\> time /T
```

4:02:04 PM

Adjusting the Time Zone

Windows CE 6.0 supports Time Zone setting. You can use **Control Panel → Date/Time** to adjust your current Time Zone. **Daylight saving Date** and **Daylight saving Time** are also supported.

Starting and Stopping Services

After boot-up, the V2101-CE computer runs several services continuously to serve requests from users or other programs. Notable services include Telnet (“TEL0:”), world wide web HTTP (“HTP0:”), and file transfer FTP (“FTP0:”). Services can be started or stopped by using the name of the service with the command “services.”

For example, use the following command to start the FTP service:

```
\> services start FTP0:
```

Use the following command to Stop the FTP service:

```
\> services stop FTP0:
```

The V2101-CE supports the following default services:

```
TEL0:  Telnet Service
FTP0:  FTP Service
```

Troubleshooting Network Connectivity

The ipconfig tool prints the TCP/IP-related configuration data of a host including the IP addresses, gateway and DNS servers.

```
\> ipconfig /all
```

```
Windows IP configuration
```

```
Ethernet adapter Local Area Connection:
```

```
IP Address . . . . . : 0.0.0.0
Subnet Mask . . . . . : 0.0.0.0
Adapter Name . . . . . : PCI\RTCENIC2
Description . . . . . : PCI\RTCENIC2
Adapter Index . . . . . : 3
Address. . . . . : 00 90 e8 00 d6 73
DHCP Enabled. . . . . : NO
Primary WinsServer :
Secondary WinsServer:
```

```
Ethernet adapter Local Area Connection:
```

```
IP Address . . . . . : 192.168.27.23
Subnet Mask . . . . . : 255.255.255.0
Default Gateway ... : 192.168.27.254
Adapter Name . . . . . : PCI\RTCENIC1
Description . . . . . : PCI\RTCENIC1
Adapter Index . . . . . : 65538
Address. . . . . : 00 90 e8 00 d6 72
DHCP Enabled. . . . . : YES
DHCP Server. . . . . : 192.168.1.97
Primary WinsServer : 192.168.1.91
Secondary WinsServer: 192.168.1.93
Lease obtained on   : Monday, January 4 ,2010 7 : 25 : 12
```

```
Lease expires on   : Tuesday, January 5 ,2010 7 : 25 : 12
AutoConfig Enabled : YES

Host name..... : V2101-CE
Domain Name..... : moxa.com
DNS Servers..... : 192.168.1.91
                  192.168.1.93
                  192.168.1.97
NODETYPE..... : 8      Routing Enabled.... : NO
Proxy Enabled..... : NO
```

To troubleshoot network connectivity, reach ability, and name resolution, use the ping command. This command verifies IP-level connectivity to another TCP/IP computer by sending Internet Control Message Protocol (ICMP) Echo Request messages. The corresponding return Echo Reply messages are displayed, along with round-trip times. For more information, type ping without parameters.

```
\> ping www.moxa.com
Pinging Host www.moxa.com [192.168.1.16]
Reply from 192.168.1.16: Echo size=32 time<1ms TTL=126
Reply from 192.168.1.16: Echo size=32 time<1ms TTL=126
Reply from 192.168.1.16: Echo size=32 time<1ms TTL=126
```

The **route** utility allows you to view or modify network routing tables. Type this command without parameters to view a list of functions.

```
\> route
```

To view current routing items in the tables,

```
\> route PRINT
```

To add a routing item on network interface 1,

```
\> route ADD 192.168.0.0 MASK 255.255.0.0 192.168.15.254
```

To delete a routing item,

```
\> route DELETE 192.168.0.0
```

Simple Network Management Protocol (SNMP)

SNMP is the standard Internet protocol for network management, and is part of the TCP/IP protocol suite. SNMP was developed to monitor and manage networks. It uses a distributed architecture that consists of agents and managers:

SNMP Agent

The SNMP agent is an SNMP application that monitors network traffic and responds to queries from SNMP manager applications. The agent also notifies the manager by sending a trap when significant events occur.

SNMP Manager

An SNMP manager is an SNMP application that generates queries to SNMP agent applications and receives traps from SNMP agent applications.

The V2101-CE computer installs an SNMP agent to serve as an SNMP device. You should install the SNMP manager on the workstation computer (for example, a Linux system) that monitors the network. After installing the nodes, you need to configure the SNMP manager and agent.

To check SNMP agent capabilities for a target V2101-CE computer (e.g, network IP at 192.168.3.127), log in to the workstation computer on which the SNMP manager resides. For example, for a Linux-based computer type:

```
\> snmpwalk -v 2c -c public 192.168.3.127 system

SNMPv2-MIB::sysDescr.0 = STRING: Microsoft Windows CE Version 6.0 (Build
2217)

SNMPv2-MIB::sysObjectID.0 = OID:
SNMPv2-SMI::enterprises.8691.13.2101

DISMAN-EVENT-MIB::sysUpTimeInstance = Timeticks: (7998235)
22:13:02.35

SNMPv2-MIB::sysContact.0 = STRING: MOXA Inc. Embedded Computing
Business

SNMPv2-MIB::sysName.0 = STRING: V2101-CE

SNMPv2-MIB::sysLocation.0 = STRING:F8, No 6, Alley 6, Lane 235,
Pao-Chiao Rd. Shing Tien City, Taipei, Taiwan, R.O.C.

SNMPv2-MIB::sysServices.0 = INTEGER: 72


SNMPv2-MIB::sysORLastChange.0 = Timeticks: (0) 0:00:00.00
```

You will see a series of messages from the SNMP agent on the V2101-CE computer. You will now be able to monitor and manage the computer.

Setting Up the LVDS Panel

BIOS configuration

In the BIOS setting, select **LCD Panel Type**, and then select the correct resolution.



LVDS synchronization utility


After entering Windows CE, there is an auto-launching program for synchronizing the CRT (D-Sub) and LVDS. The utility will configure the setting automatically if the resolution of LVDS is not the same as CRT.

The utility will perform the changes after 10 seconds if you do not cancel it.




Note: If you use signal display, you can turn off the LVDS with the System Manager's Display setting.

To check the configuration, select the System Manager's **Display** tab.



Inserting a USB Storage Device into the Computer

When the first USB storage device is plugged into the V2101-CE, a directory named **USBDisk** under the root directory on the internal file system is created as a link to the storage area. The directory created for the second USB device is **USBDisk2**.



ATTENTION

We suggest formatting your USB Disk with the FAT format since the V2101-CE does not support the NTFS format.

2 RS-232/422/485 Serial Ports

The V2101-CE computer's two RS-232/422/485 serial ports, listed from bottom to top, are named **COM1:** and **COM2:**. Each of these ports supports baudrate settings up to 115200 bps.

Accessing Files through File Sharing

A file server function is provided for transferring files to the V2101-CE. **On PC**, Click **Start** → **Run** and input \\x.x.x.x to invoke the following login window.

Note: x.x.x.x stands for V2101-CE's IP address. After logging in, you will find 2 RS-232/422/485 Serial Ports that a file sharing folder has been created.



To manage file sharing, type the “**netshare -h**” command from any command window (either Telnet or console).

```

c:\ Telnet 192.168.27.23
Welcome to the Windows CE Telnet Service on U2101-CE
MOXA Firmware Version U1.0 Build 09122915
login: admin
Password:
Pocket CMD v 6.00
\> netshare -h
netshare [-h] [-s <ShareName> <SharePath> -a <User1;User2;User3>] [-r <ShareName>]
>|
  e.g. netshare -h
       ; Show this help
  e.g. netshare
       ; Display all shared folder
  e.g. netshare -s docs "\\My Documents" -a admin
       ; Share "\\My Documents" folder as "docs" shared name for user "admin"
\>


```

BIOS Status Notification


The notification window provides users with immediate system status updates through the two following types of message:

- **CMOS Checksum Error**-Some situations, such as low battery or when the CMOS is cleared, will cause the CMOS checksum error and the notification window shows.

Note: If you update the new bios and reboot the device, you will see the notification windows pop up because the checksum has been changed. Simply close the window for the new setting.



- **Keyboard Error**-If the keyboard was not installed in booting process, the notification window will pop up.




In addition, you can get the status change by programming. For example, you can get “BIOS Status” from `\examples\C++\` in the Software DVD.

The code snippet is as follows:

```
#define BIOS_CMOS_CHECKSUM                0x40
#define BIOS_KEYBOARD_ERROR              0x2
ErrorCode=Get_BIOS_Status();
Checksum_Error=(ErrorCode & BIOS_CMOS_CHECKSUM ? 1:0);
Keyboard_Error=(ErrorCode & BIOS_KEYBOARD_ERROR ? 1:0);
```

This function can be disabled or enabled by system manager; you can remove the auto launch item from system manager and enable it by adding the auto launch item under windows directory. The program name is “**BIOSAlarm.exe**”.



How to Determine the Firmware Build Version

Use the `mxver` command to obtain the firmware version. This information is particularly important for identifying which features your embedded computer supports.

Issue the `sysinfo.exe` command from the command line utility.

```
C:\> sysinfo
```

```
PCI\RTCENIC1=00-90-e8-00-d6-72
```

```
PCI\RTCENIC2=00-90-e8-00-d6-73
```

```
Host: V2101-CE
```

```
Firmware:V1.0
```

```
Build:09122915
```

```
.NetCF:3.5
```

```
ModelName:V2101-CE
```

```
192.168.27.23
```

```
Memory: 436948992 / 491102208 (Bytes)
```

```
File System Free Space:
```

```
[ \ ] 1015545856 / 1048379392 (Bytes)
```

```
\>
```


The V2101-CE ready-to-run embedded computer is shipped with Window CE operating system pre-installed. This operating system was designed to serve as a front-end for data acquisition and industrial control applications. A user-friendly management utility is also installed on each V2101-CE computer to handle management issues. Before using this utility, make sure you have a display monitor connected to your V2101-CE embedded computer, and then double-click the **System Manager** desktop icon.

This chapter covers the following topics:

- System Information**
- Serial Port Configuration**
- Process (Thread) Monitoring/Control**
- Services Monitoring/Control**
- DisplayUser/Group Management**
- Auto Launch Configuration**
- Web Server Configuration Page**

System Information


The first page displays the V2101-CE's system information, including the firmware version of the computer, the Net CF version, the system time, and system resources, including the main memory and file system usage.



Serial Port Configuration


The V2101-CE has 2 RS-232/422/485 serial ports. You may use the drop-down list to configure the operation mode.

See the following figure for detailed information.




Process (Thread) Monitoring/Control

You can use the management system to monitor and control processes or threads. The V2101-CE computer can manage up to 32 processes. To view current processes, click the **Processes** item on the tab bar. Processes that are currently running will be displayed. You can kill a process by clicking the **kill** button.



Services Monitoring/Control

Some services—such as FTP, Telnet and HTTP—run in the background. Click on a check box to toggle a start/stop operation for a particular service.





You can also adjust the time automatically by using SNTP. Click on the check box to enable the service and then click the button next to the box to activate it.

In order to keep the computer running normally, some listed services cannot be stopped. This type of service does not have a check box next to it.

Display

The V2101-CE VGA output uses a DB15 female connector to display the Windows CE desktop on an LCD monitor or a CRT monitor. The default settings are **800x600, 16 bit, 60 Hz**. You should tune the setting to match your monitor's specifications. After setting these parameters on the **System Manager** → **Display** window, click **Apply** to save the settings to the computer, and then click **Yes** to restart the computer.





**ATTENTION**

You must restart (reboot) the system for the settings to take effect.


User/Group Management

You can add users by clicking the “**Add**” button to assign user name and group. And you can remove users by click the “**Remove**” button.






Enter the **administrator password** when you want to remove a user.



Auto Launch Configuration


You can specify programs to execute automatically after booting up. Click the **Add** button to add the program and restart the V2101-CE to execute these programs.




Web Server Configuration Page

You can configure the V2101-CE with an Internet browser. Your host must be running Windows 2000 or Windows XP to handle web administration. To do this, start Internet Explorer and then link to the url <http://192.168.3.127/WebAdmin> (if the V2101's IP address is 192.168.3.127).


After the logging in, you should see the standard Web Server Configuration page.



From this page you can create a new web site or create a virtual web path for your web application.



You can also change the authentication type for each web virtual directory.



4

System Recovery

The V2101-CE ready-to-run embedded computers run the Windows CE 6.0 operating system. In this chapter, we describe the recovery process that occurs in the event of system instability.


This chapter covers the following topics:

- ❑ **Reset to Factory Default**
- ❑ **Recovery Procedure**
 - Recovery Environment


Reset to Factory Default

We suggest that you run the “reset to factory default” procedure, so that the system can run from its default configuration. Take the following steps to do this:

1. Double-click **Reset to Default** from the **Control Panel**.



2. Click **Yes** to continue, or **No** to cancel.



3. Click **Yes** in the next screen, or **No** to cancel.



4. The V2101-CE computer will start booting up. When you hear the beep and see the WinCE loader image, press **8** to invoke the reset-to-default procedure.
5. The V2101-CE will automatically scan the file system and fix possible problems.
6. When finished, you will see **Are you sure you would like to reset the system configuration to the default? (y/n)**. Enter **Y** to continue.
7. When you see **Are you sure to clean all files? (y/n)** enter **Y** to continue.
8. Next, you will see **Proceeds? (y/n)**. Enter **Y** to continue.
9. The default settings will be loaded in the V2101-CE computer.
10. When finished, the V2101-CE computer will reboot, and the reset-to-default procedure will be complete.


Recovery Procedure

This section describes the recovery procedure. However, system recovery requires sophisticated operation and may damage your computer if not operated properly. Please contact Moxa's technical support staff for all the necessary tools and assistance.

Please follow the steps below.

Recovery Environment


The recovery environment includes the V2101-CE embedded computer and a bootable USB disk with the recovery programs and system image file.



Step 1: Format an Empty USB Disk.

Use the HP USB Disk Format Tool.

1. Download the FreeDOS system files **kernel.sys** and **command.com** from <http://www.freedos.org/kernel/>
2. Copy the DOS system files **kernel.sys** and **command.com** to a specified directory (in this example, **C:\FreeDOS**).
3. Start the HP USB Disk Storage Format Tool and select the USB device that you want to use as a bootable disk from the **Device** drop down box.




4. Select FAT from the **File system** drop down box.
5. Type the disk name in the **Volume label** field.
6. Check the option **Create a DOS startup disk** under format options.
7. Specify the directory of the system files (e.g., **C:\FreeDOS**).
8. Click **Start** to format and create the USB disk.

**ATTENTION**

The HP USB Disk Storage Format Tool can be downloaded from many different web sites. Type **HP USB Disk Storage Format Tool** to search the Internet, and then download it.


Step 2: Create a Windows CE Bootable USB Disk.

- a. The **ceboot** directory is located under **\utility_tools\Recovery\CEBOOT** on the CD shipped with V2101-CE computer.
- b. Configure Windows Explorer to show hidden files (including protected operating system files).
- c. Copy all of the files in the **ceboot** directory to the root directory of your USB disk.




Step 3: Setup the BIOS to Boot from the USB Disk.

- a. Insert the USB disk.
- b. Power on and press **DEL** to enter the bios setup menu.
- c. Select **Advanced** → **Hard Disk Boot Priority** and then press **Enter**.
- d. From the setup menu, use “↑” or “↓” to select the USB device
- e. Press “+” to move it up to the first priority, and press **Esc** to exit the setup menu.



- f. Make sure the first boot device is **Hard Disk**. If not, press **Enter** to change it.




- g. Select **Exit** → **Save & Exit Setup** and then press **Enter**.
- h. Choose **Y** to save to the CMOS and then exit.




ATTENTION

Please note that some USB disks will be detected as a **Removable Device**. If it happens, perform the following bios modification.


- a. Select **Removable Device Priority**.



- b. Make sure that the USB disk has been detected. Press **Esc** to exit.



- c. Make sure that the **First Boot Device** is set to **Removable**. If not, select **First Boot Device**, press **Enter** and select it from the list.



- d. Select **Exit → Save & Exit Setup** and then press **Enter**.
- e. Choose **Y** to save to the CMOS and then exit.

Step 4: Recover Windows CE system from the USB Disk.

- f. If the BIOS setup is correct, it will restart and boot from the USB disk.
- g. Under command prompt, type **cd ceboot**.
- h. In the ceboot directory type **mkdisk** to execute the recovery procedure.
- i. When operation is complete, turn off the computer and remove the USB disk.



ATTENTION

DO NOT turn off power at this time, or the system may crash.

Step 5: Reset the BIOS to boot from the DOM or CompactFlash Disk.


- a. Power on and press **DEL** to enter the bios setup menu.
- b. Select **Advanced → Hard Disk Boot Priority** and then press **Enter**.
- c. From the setup menu, use “↑” or “↓” to select the DOM or CompactFlash device.
- d. Press “+” to move it up to the first priority, and press “Esc” to exit the setup menu.
- e. Select **Exit → Save & Exit Setup** and then press **Enter**.
- f. Choose **Y** to save to the CMOS and then exit.
- g. Wait a few minutes for the system to boot up. When the recovery process is finished, you will again see the Windows CE desktop.

A

Firmware Upgrade Procedure

Moxa's engineers continuously enhance and develop software features to improve the quality and functionality of the embedded products, with new firmware available from Moxa's download center. Take the following steps when you decide to replace your firmware.


1. Go to the Moxa download center to download an executable file for your computer; for example V2101-CE_V1.0.09112414.exe.
2. Upload this file to the target machine under the root directory (i.e., \). If you place this file in a Compact Flash or a USB device, we suggest that you copy it to the root directory for a faster upgrade operation. Directly executing the program in a USB 1.1 device is very slow.
3. Log on to the target computer via a Telnet connection.
4. Execute this file. Press Y to continue the process.



```
c:\ Telnet 192.168.30.204
\> FWUpgrade
The new firmware is U2100 U1.0

Welcome to the utility of the firmware upgrade program provided by Moxa Technology. This program overwrites the firmware image that was stored in the flash. The settings you have ever made to the computer may be wiped out. Please BACKUP files before you continue this process! During the upgrade process, please do not plug off the power supply. Otherwise, incomplete process would damage the flash and force the computer into a disable state. After the upgrade is completed, power the computer again.
The time spent of this procedure depends on where the upgrade program resides. It takes about 1 minute to complete.

Continue the process? (y/n)_
```




```
c:\ Telnet 192.168.30.204
\> FWUpgrade
The new firmware is U2100 U1.0

Welcome to the utility of the firmware upgrade program provided by Moxa Technology. This program overwrites the firmware image that was stored in the flash. The settings you have ever made to the computer may be wiped out. Please BACKUP files before you continue this process!!. During the upgrade process, please do not plug off the power supply. Otherwise, incomplete process would damage the flash and force the computer into a disable state. After the upgrade is completed, power the computer again.
The time spent of this procedure depends on where the upgrade program resides. It takes about 1 minute to complete.

Continue the process? <y/n>y
The firmware upgrade procedure may take 1 minute, please wait..

4980736 / 20272871_
```

5. The upgrade will take about 1 minute. After the upgrade is complete, select if you would like to keep the current network settings or restore the factory default values. Press Y to keep the current network settings.



```
c:\ Telnet 192.168.30.204
20272871 / 20272871
Firmware upgrade complete!
LAN1 Interface Configuration:
IP Address:
SubNet Mask:
Gateway:
DNS:
WINS:
LAN2 Interface Configuration:
IP Address:
SubNet Mask:
Gateway:
DNS:
WINS:
Do you want to keep the current network settings on the next boot <Y/N>?_
```

When the system restarts, the new firmware will be ready and running.